



9840 Windmill Road, Bldg. 200, Houston, TX 77064 Email: Hendrix5@peoplepc.com Phone: 713-466-6888

## **Sample Cooler**

### **Installation:**

Install the cooler on its legs or with the mounting plate whichever you have. Be certain it is oriented properly so the cooling fluid inlet lines up with the cooling fluid line. Also make certain the sample "In" and sample "Out" lines are lined up with their respective attachment fittings.

Attach and tighten the cooling fluid lines. Attach and tighten the sample lines.

### **Operation:**

Open the cooling fluid line and check to make certain there are no leaks. Open the sample line. It is a good idea to check the sample and determine if the sample is cooled to the expected temperature range.

### **Spare Parts:**

There are no spare parts:

### **Maintenance:**

If it is a closed system there is very little maintenance other than checking for leaks occasionally. If it is an open system you should check and clean the coil occasionally if necessary to maintain positive heat transfer.

Hendrix Specialty Fabrication, Inc.